













Note: Refer to the a315 Owner's Manual page 10 for additional connection information.

Connection Legend:

<i>Data Cable*</i> -		<i>Digital Signal Cable</i> -	
<i>Sensor Cable</i> -		<i>Network/RS232 Cable</i> -	
<i>Trigger Control Cable*</i> -		<i>Ground Wire</i> -	
<i>Audio Signal Cable</i> -		<i>AC Power Cords</i> -	
<i>Video Signal Cable</i> -		<i>Loudspeaker Cable</i> -	
<i>RF Signal Cable</i> -			

** 2 conductor shielded with 3.5mm stereo mini phone plug on each end.*

* 2 conductor shielded with 3.5mm stereo mini phone plug on each end.



Caution: The Loudspeaker Output \ominus Negative Terminal Connections are not connected to chassis ground. Do not combine any of the Loudspeaker Output Terminals (\oplus Positive or \ominus Negative) connections together, ground them or connect with another amplifier.

Note: Refer to the a315 Owner's Manual page 12 for additional connection information.

Connection Legend:

- Data Cable* - — Digital Signal Cable - —
 - Sensor/Keypad Cable - — Network/RS232 Cable - —
 - Trigger Control Cable* - — Ground Wire - —
 - Audio Signal Cable - — AC Power Cords - —
 - Video Signal Cable - — Loudspeaker Cable - —
 - RF Signal Cable - —
- * 2 conductor shielded with 3.5mm stereo mini phone plug on each end.

